





60x80 cm






Manual for Rectangular Mirror







Necessary tools before Install



Installation step

How to Make holes on the wall



if you mirror has this function

Testing Mirror working



press both anti-fog key and light key to adjust time and please note that time and temperature will be auto-cycle displaying every 15 seconds